

Наименование	Модель принтера, МФУ	Ресурс	Запр	Восст
		Тысяч копий	Руб.	Руб.
<b>Brother</b>				
TN-2075/TN350	Brother HL-2030R/2040R/2070NR/DCP-7010R/7025R	2,5	490	
TN-2085/TN360	Brother HL-2035R	2,5	490	
TN-2135/TN-2175	Brother HL-2140/2150/2170, DCP-7030/7032/7045, MFC-7320R/7440 /7840	2,5	490	
TN-3030	Brother HL-5130/5140/5150D/5170DN	3,5	690	
TN-3060 / TN-7600	Brother HL-5130/5140/5150D/5170DN	6,5	790	
TN-3170 / TN580 / TN-3280 /TN-3130	Brother HL-5240/5250/5270DN/5280DW/ MFC8860DN/ DCN8060/8065	6	750	
TN-4100	Brother HL-6050/6050D/6050DN	7,5	850	
TN-7600 / TN-3060	Brother HL-1260e/1650/1670N/1850/1870N	6,5	790	
DR-2075	Brother HL-2030R/2040R/2070NR/DCP-7010R/7025R	12		750
DR-2085	Brother HL-2035R	12		950
DR-2175	Brother HL-2140/2150/2170, DCP-7030/7045, MFC-7320R/7440	12		750
TN-3280 / TN-3170 / TN580	Brother HL-5340D / 5350DN / 5370DW / DCP-8085DN	8	850	
DR-3100 (Drum-unit)	Brother HL-5240/5250/5270DN/5280DW/MFC8860DN/ DCN8060/8065	25		950
DR-3200 (Drum-unit)	HL-5340D / 5350DN / 5370DW / DCP-8085DN	25		970
TN-2275	Brother HL2240/2240D/2250DN	2,6	490	
DR-2275 (Drum-unit)	Brother HL2240/2240D/2250DN/2132R/ DCP-7057R	12		1050
TN-2080	Brother HL-2130R / DCP-7055R	2,5	490	
TN-2090	Brother HL-2132R / DCP-7057R	1	450	
DR-2080 (Drum-unit)	Brother HL-2130R / DCP-7055R	12		1050
TN-3380	Brother HL-5440D/5450DN/5470DW/6180DW/DCP-8110DN/8250DN/MFC-8520DN/8950DW	8	950	
TN-3390	Brother HL6180DW/DCP8250DN/MFC8950DW	12	1150	
DR-3300	Brother HL-5440D/5450DN/5470DW/6180DW/DCP-8110DN/8250DN/MFC-8520DN/8950DW	30		1450
TN-1075	Brother HL-1110/ 1112/ DCP-1510/ 1512 / MFC-1810 /1815	1	490	
DR-1075 (Drum-unit)	Brother HL-1110/ 1112/ DCP-1510/ 1512 / MFC-1810 /1815	10		1350
TN135BK	Brother HL-4040CN/4050CDN/ DCP-9040CN/MFC-9440CN	5	1150	
TN135C	Brother HL-4040CN/4050CDN/ DCP-9040CN/MFC-9440CN	4	950	
TN135M	Brother HL-4040CN/4050CDN/ DCP-9040CN/MFC-9440CN	4	950	
TN135Y	Brother HL-4040CN/4050CDN/ DCP-9040CN/MFC-9440CN	4	950	
TN-230BK	Brother HL3040/3070/DCP9010CN/MFC9120CN	2,2	1250	

TN-230C	Brother HL3040/3070/DCP9010CN/MFC9120CN	1,4	1150	
TN-230M	Brother HL3040/3070/DCP9010CN/MFC9120CN	1,4	1150	
TN-230Y	Brother HL3040/3070/DCP9010CN/MFC9120CN	1,4	1150	
TN-325Bk	Brother DCP-9055/9270, HL-4140/4150/4570, MFC-9460/9465//9970	4	1650	
TN-325C	Brother DCP-9055/9270, HL-4140/4150/4570, MFC-9460/9465//9970	3,5	1550	
TN-325M	Brother DCP-9055/9270, HL-4140/4150/4570, MFC-9460/9465//9970	3,5	1550	
TN-325Y	Brother DCP-9055/9270, HL-4140/4150/4570, MFC-9460/9465//9970	3,5	1550	
TN-241Bk	Brother HL3140/ HL3150/ HL3170/ DCP9020/ MFC9130/ MFC9140/ MFC9320/ MFC9330/ MFC9340	2,5	1450	
TN-245C	Brother HL3140/ HL3150/ HL3170/ DCP9020/ MFC9130/ MFC9140/ MFC9320/ MFC9330/ MFC9340	2,2	1450	
TN-245M	Brother HL3140/ HL3150/ HL3170/ DCP9020/ MFC9130/ MFC9140/ MFC9320/ MFC9330/ MFC9340	2,2	1350	
TN-245Y	Brother HL3140/ HL3150/ HL3170/ DCP9020/ MFC9130/ MFC9140/ MFC9320/ MFC9330/ MFC9340	2,2	1350	
<b>Canon</b>				
509/ Q7516A	Canon LBP3500/3900/3950 // HP LJ 5200	12	1450	1650
706	Canon LaserBase MF6530/40PL/50/60PL/80PL	5	790	950
703 / Q2612A	Canon LBP 2900 // HP LJ 1010/1012/1015/1018/1020/1022	2	350	490
708H / Q5949X	Canon LBP3300 / 3360 // HP LJ1320/1160/3390/3392/	6	570	890
712 / CB435A	Canon LBP3100/LBP3010 // HP LJ P1005,/06,/07, /08/	1,5	370	490
A30	Canon FC 1/2/3/5 // PC 6/7/7RE/11	3,5	690	890
Canon Cartridge T	Canon PC-D320/340, FAX L380/L390/L400	3,5	670	890
E-16	Canon FC1xx/2xx/3xx PC7xx/8xx	3	450	790
E-30	Canon FC1xx/2xx/3xx PC7xx/8xx	3,5	450	790
EP-22 / C4092A	Canon LBP 800/810/1120 // HP LJ 1100/3200	2,5	590	690
EP-25 / FX-8 / C7115A	Canon LBP-1210 // HP LJ 1000/1005/1200/1220/3300/3330/3380	2,5	590	690
EP-27	Canon LBP3200/MF3110/3228/5630/5650/5730/5750/5770	2,5	590	690
EP-32 / EP-42 / C4096A	Canon LBP 1000 // HP LJ 2100/ 2200	5	750	890
EP-52 / C4127A	Canon LBP 1760/1760e // HP LJ 4000/ 4050	6	670	790
EP-62 / C4129X	Canon LBP-1610/20/1810 // HP LJ 4000/ 4050	10	850	1350
EP-A / C3906A	Canon LBP-440/445/460/465/660 // HP LJ 5L/ 6L/ 3100	2,5	590	690
EP-W (WX) /C3909A	Canon LBP 2460 // HP LJ 5Si MX/NX/ 8000	15	1590	1790
FX-10	Canon L100/120/140/160/MF4010/4018/4660PL/4690PL	2,5	350	490

713 / CB436A	Canon LBP3250 // HP LJ 1505 / M1120 / M1522	2	390	550
728 /CE278A	Canon i-SENSYS MF4410/4430/4450/4550/4570/4580	2,1	390	550
708 / 5949A	Canon LBP3300 / 3360 // HP LJ 1160/1320/3390/3392	2,5	770	690
710 / 6511A	Canon LBP 3460 // HP LJ 2400 / 2410 / 2420 / 2430	6	990	1250
710H / 6511X	Canon LBP 3460 // HP LJ 2400 / 2410 / 2420 / 2430	12	1390	1550
719 / 505A	Canon LBP 6300 / 6650 / MF5840 / MF5880 // HP LJ P2035/2055	2,3	670	890
719H / 505X	Canon LBP 6300 / 6650 / MF5840 / MF5880 // HP LJ P2055	6,5	770	950
724 / 255A	Canon i-SENSYS LBP6750Dn // HP LJ P3011 / P3015	6	1390	1490
724H / 255X	Canon i-SENSYS LBP6750Dn // HP LJ P3015	12,5	1590	1650
725 / 285A	Canon LBP 6000 / MF3010 // HP LJ P1102/ P1102W /M1212NF	1,6	370	490
C-EXV18/GPR-22/NPG-32 Drum-unit	Canon iR1018/ 1020/ 1022/ 1024	27		950
C-EXV5/ GPR-8/ NPG-20 Drum-unit	Canon IR1600/ iR1605/ iR1610/ iR1630/ iR1670/ iR2000/ iR2010	21		1550
707BK / Q6000A Bk	Canon LBP-5000 // HP LJ 1600/2600/	2,5	870	970
707C / Q6001A C	Canon LBP-5000 // HP LJ 1600/2600/	2	870	970
707Y / Q6002A Y	Canon LBP-5000 // HP LJ 1600/2600/	2	870	970
707M / Q6003A M	Canon LBP-5000 // HP LJ 1600/2600/	2	870	970
701Bk / Q3960A Bk	Canon LBP5200 / I-SENSYS MF 8180C // HP LJ Color 2550/2820/2840	5	1170	
701C / Q3961(71)A C	Canon LBP5200 / I-SENSYS MF 8180C // HP LJ Color 2550/2820/2840	4	1170	
701Y / Q3962(72)A Y	Canon LBP5200 / I-SENSYS MF 8180C // HP LJ Color 2550/2820/2840	4	1170	
701M / Q3963(73)A M	Canon LBP5200 / I-SENSYS MF 8180C // HP LJ Color 2550/2820/2840	4	1170	
716Bk / 540A	Canon LBP-5050 /MF8030 /MF8050 /MF8080 // HP CLJ CP1215//1515/1518/CM1312	2,2	770	950
716C / 541A	Canon LBP-5050 /MF8030 /MF8050 /MF8080 // HP CLJ CP1215//1515/1518/CM1312	1,4	770	950
716Y / 542A	Canon LBP-5050 /MF8030 /MF8050 /MF8080 // HP CLJ CP1215//1515/1518/CM1312	1,4	770	950
716M / 543A	Canon LBP-5050 /MF8030 /MF8050 /MF8080 // HP CLJ CP1215//1515/1518/CM1312	1,4	770	950
718Bk / 530A	Canon LBP-7200 / MF8330 / MF-8350 // HP CLJ CP2025/CM2320	3,5	790	970
718C / 531A	Canon LBP-7200 / MF8330 / MF-8350 // HP CLJ CP2025/CM2320	2,8	790	970
718Y / 532A	Canon LBP-7200 / MF8330 / MF-8350 // HP CLJ CP2025/CM2320	2,8	790	970
718M / 533A	Canon LBP-7200 / MF8330 / MF-8350 // HP CLJ CP2025/CM2320	2,8	790	970
729Bk / 310A	Canon LBP-7010 / LBP-7018 // HP CLJ CP1025	1,2	750	
729C / 311A	Canon LBP-7010 / LBP-7018 // HP CLJ CP1025	1	750	
729Y / 312A	Canon LBP-7010 / LBP-7018 // HP CLJ CP1025	1	750	

729M / 313A	Canon LBP-7010 / LBP-7018 // HP CLJ CP1025	1	750	
723Bk	Canon i-SENSYS LBP7750/ 7750CDN/7750CD	5	1790	2090
723H Bk	Canon i-SENSYS LBP7750/ 7750CDN/7750CD	10	1990	2290
723C	Canon i-SENSYS LBP7750/ 7750CDN/7750CD	8	1790	2090
723Y	Canon i-SENSYS LBP7750/ 7750CDN/7750CD	8	1790	2090
723M	Canon i-SENSYS LBP7750/ 7750CDN/7750CD	8	1790	2090
731Bk	Canon LBP 7100Cn/ 7110Cw	1,4	790	970
731H Bk	Canon LBP 7100Cn/ 7110Cw	2,4	790	1170
731C	Canon LBP 7100Cn/ 7110Cw	1,5	1190	1390
731Y	Canon LBP 7100Cn/ 7110Cw	1,5	1190	1390
731M	Canon LBP 7100Cn/ 7110Cw	1,5	1190	1390
<b>HP</b>				
C3903A / EP-V	HP 5P / 5MP / 6P/ 6MP// Canon LBP-V406	4	790	990
C3906A / EP-A	HP LJ 5L/ 6L/ 3100 //Canon LBP-440/445/460/465/660	2,5	590	690
C3909A/ EP-W	HP LJ 5Si MX/NX/ 8000//Canon LBP 2460	15	1650	1850
C4092A / EP-22	HP LJ 1100/3200//Canon LBP-800/810/1110/1120	2,5	590	690
C4096A / EP-32 / EP-42	HP LJ 2100/ 2200 // Canon LBP 1000/1310	5	890	950
C4127A / EP-52	HP LJ 4000/ 4050 // Canon LBP 1760/1760e	6	590	700
C4127X / EP-52	HP LJ 4000/ 4050 // Canon LBP 1760/1760e	10	750	890
C4129X / EP-62	HP LJ 5000/5100 // Canon LBP-1610/20/1810	10	1050	1350
C4182X	HP LJ 8100/Mopier 320	20	1490	1600
C7115A / EP-25 / FX-8	HP LJ 1000/1005/1200/1220/3300/3330/3380//Canon LBP-1210	2,5	570	670
C7115X	HP LJ 1000/1005/1200/1220/3300/3330/3380//Canon LBP-1210	5	590	690
C8061A	HP LJ 4100	6	950	1100
CB435A / 712	HP LJ P1005/06/// Canon LBP3100/3010	1,5	370	490
CB436A / 713	HP LJ 1505 / M1120 / M1522 // Canon LBP3250	2	370	490
CC364A	HP LJ P4014 / P4015 / P4515	10	950	1100
CC364X	HP LJ P4015 / P4515	24	1190	1300
CE255A / 724	HP LJ P3011 / P3015	6	690	800
CE255X / 724H	HP LJ P3015	12,5	890	1150
CE505A / 719	HP LJ P2035 / P2055	2,3	450	550
CE505X / 719H	HP LJ P2055	6,5	590	690

Q1338A	HP LJ 4200	12	1350	1570
Q1339A	HP LJ 4300	18	1350	1570
Q2610A	HP LJ 2300	6	890	950
Q2612A / 703	HP LJ 1010/1012/15/20/3030/50 // Canon LBP 2900	2	350	490
Q2612X	HP LJ 1010/1012/1015/3015/3020	3	380	520
Q2613A	HP LJ 1300	2,5	390	450
Q2613X	HP LJ 1300	5	410	470
Q2624A	HP LJ 1150	2,5	650	770
Q5942A	HP LJ 4250/4350	10	1390	1550
Q5942X	HP LJ 4250/4350	20	1490	1690
Q5945A	HP LJ 4345, M4345	18	1590	1790
Q5949A / 708	HP LJ 1160/1320/3390/3392 // Canon LBP3300 / 3360	2,5	550	690
Q5949X / 708H	HP LJ 1160/1320/3390/3392 // Canon LBP3300 / 3360	6	650	790
Q6511A / 710	HP LJ 2400/ 2410/ 2420/ 2430	6	850	920
Q6511X / 710H	HP LJ 2400/ 2410/ 2420/ 2430	12	890	1150
Q7516A / 509	HP LJ 5200 // Canon LBP3500/ 3900/ 3950	12	1390	1570
Q7551A	HP LJ P3005 / M3027 / M3035	6,5	750	830
Q7551X	HP LJ P3005 / M3027 / M3035	13	790	930
Q7553A	HP LJ P2014/ P2015/M2727	3,5	450	550
Q7553X	HP LJ P2014/ P2015/M2727	7	590	690
Q7570A	HP LJ M5025mfp/M5035mfp	15	1490	1650
C8543X	HP LJ 9000/9040/9050	30	2690	2820
CE278A / 728	HP LJ P1560/ P1566/ P1606/ M1530/ M1536/ M1537/ M1538/ M1539	2,1	370	490
CE285A / 725	HP LJ P1100/1101/1102/1103/1104/1106/1108/1109/ M1130/1132/1137/1210/1212/1214/1217/1218/1219	1,6	370	490
435/436/278/285 Universal	HP LJ P1005/ 1006/ 1505/ M1120/ M1522/ P1007/ 1008/ P1566/ 1606/ 1102/ M1212// Canon LBP3100/ 3010/ 3250	2,1	410	570
CF280A	HP LJ Pro 400 M401/ Pro 400 MFP M425	2,5	450	550
CF280X	HP LJ Pro 400 M401/ Pro 400 MFP M425	6,9	590	690
CF283A	HP LJ Pro MFP M125/ M127	1,5	950	1150
C9700A	HP CLJ 1500/2500	5	970	1150
C9701A	HP CLJ 1500/2500	4	970	1150
C9702A	HP CLJ 1500/2500	4	970	1150
C9703A	HP CLJ 1500/2500	4	970	1150

C9720A	HP CLJ 4600/ 4610/ 4650	9	1490	1650
C9721A	HP CLJ 4600/ 4610/ 4650	8	1490	1650
C9722A	HP CLJ 4600/ 4610/ 4650	8	1490	1650
C9723A	HP CLJ 4600/ 4610/ 4650	8	1490	1650
C9730A	HP CLJ 5500/5550	13	2390	2550
C9731A	HP CLJ 5500/5550	12	2390	2550
C9732A	HP CLJ 5500/5550	12	2390	2550
C9733A	HP CLJ 5500/5550	12	2390	2550
CB400A	HP CLJ CP4005	7,5	1970	2270
CB401A	HP CLJ CP4005	7,5	1970	2270
CB402A	HP CLJ CP4005	7,5	1970	2270
CB403A	HP CLJ CP4005	7,5	1970	2270
CB540A / 716Bk	HP CLJ CP1215//1515/1518/CM1312	2,2	650	750
CB541A / 716C	HP CLJ CP1215//1515/1518/CM1312	1,4	650	750
CB542A / 716Y	HP CLJ CP1215//1515/1518/CM1312	1,4	650	750
CB543A / 716M	HP CLJ CP1215//1515/1518/CM1312	1,4	650	750
CC530A / 718Bk	HP CLJ CP2025/CM2320	3,5	890	1030
CC531A / 718C	HP CLJ CP2025/CM2320	2,8	890	990
CC532A / 718Y	HP CLJ CP2025/CM2320	2,8	890	990
CC533A / 718M	HP CLJ CP2025/CM2320	2,8	890	990
Q3960A / 701Bk	HP CLJ 2550/2820/2840 // Canon LBP5200 / I-SENSYS MF 8180C	5	1220	
Q3961A / 701C	HP CLJ 2550/2820/2840 // Canon LBP5200 / I-SENSYS MF 8180C	4	1220	
Q3962A / 701Y	HP CLJ 2550/2820/2840 // Canon LBP5200 / I-SENSYS MF 8180C	4	1220	
Q3963A / 701M	HP CLJ 2550/2820/2840 // Canon LBP5200 / I-SENSYS MF 8180C	4	1220	
Q5950A	HP CLJ 4700	11	1950	2170
Q5951A	HP CLJ 4700	10	1950	2170
Q5952A	HP CLJ 4700	10	1950	2170
Q5953A	HP CLJ 4700	10	1950	2170
Q6000A / 707Bk	HP CLJ 1600/2600/ CM1015/CM1017 // Canon LBP-5000	2,5	890	1050
Q6001A / 707C	HP CLJ 1600/2600/ CM1015/CM1017 // Canon LBP-5000	2	890	1050
Q6002A / 707Y	HP CLJ 1600/2600/ CM1015/CM1017 // Canon LBP-5000	2	890	1050
Q6003A / 707M	HP CLJ 1600/2600/ CM1015/CM1017 // Canon LBP-5000	2	890	1050
Q6470A	HP CLJ 3600/3800/ CP 3505	6	1790	1950

Q6471A	HP CLJ 3600	4	1790	1950
Q6472A	HP CLJ 3600	4	1790	1950
Q6473A	HP CLJ 3600	4	1790	1950
Q2670A	HP CLJ 3500 / 3550 / 3700 /3750	6	1490	1650
Q2671A	HP CLJ 3500/ 3550	6	1490	1650
Q2672A	HP CLJ 3500/ 3550	6	1490	1650
Q2673A	HP CLJ 3500/ 3550	6	1490	1650
Q7560A	HP CLJ Color 2700 / 3000	6,5	1790	1990
Q7561A	HP CLJ Color 2700 / 3000	3,5	1790	1990
Q7562A	HP CLJ Color 2700 / 3000	3,5	1790	1990
Q7563A	HP CLJ Color 2700 / 3000	3,5	1790	1990
CE250A	HP CLJ CM3530 / CP3525	5	1790	1990
CE251A	HP CLJ CM3530 / CP3525	7	1790	1990
CE252A	HP CLJ CM3530 / CP3525	7	1790	1990
CE253A	HP CLJ CM3530 / CP3525	7	1790	1990
Q2681A	HP CLJ 3700 /3750	6	1590	1770
Q2682A	HP CLJ 3700 /3750	6	1590	1770
Q2683A	HP CLJ 3700 /3750	6	1590	1770
Q7581A	HP CLJ CP3505/ 3800	4	1790	1970
Q7582A	HP CLJ CP3505/ 3800	4	1790	1970
Q7583A	HP CLJ CP3505/ 3800	4	1790	1970
CE320A	HP CLJ CM 1415 / CP1525	2	790	970
CE321A	HP CLJ CM 1415 / CP1525	1,3	790	970
CE322A	HP CLJ CM 1415 / CP1525	1,3	790	970
CE323A	HP CLJ CM 1415 / CP1525	1,3	790	970
CE260A	HP CLJ CP4025/ CP4525/CM4540 MFP	8,5	2190	2310
CE261A	HP CLJ CP4025/ CP4525	11	2190	2310
CE262A	HP CLJ CP4025/ CP4525	11	2190	2310
CE263A	HP CLJ CP4025/ CP4525	11	2190	2310
CE310A / 729Bk	HP Color LaserJet Pro CP1025, 100 MFP 175nw	1,2	710	
CE311A / 729C	HP Color LaserJet Pro CP1025, 100 MFP 175nw	1	710	
CE312A / 729Y	HP Color LaserJet Pro CP1025, 100 MFP 175nw	1	710	
CE313A / 729M	HP Color LaserJet Pro CP1025, 100 MFP 175nw	1	710	

CE740A	HP CLJ CP5225	7	2600	2900
CE741A	HP CLJ CP5225	7,3	2690	2970
CE742A	HP CLJ CP5225	7,3	2690	2970
CE743A	HP CLJ CP5225	7,3	2690	2970
CE314A (Drum-Unit)	HP Color LaserJet Pro CP1025, 100 MFP 175nw	14		1130
CE400X	HP CLJ 500 M551	11	1850	2450
CE401A	HP CLJ 500 M551	6	1890	2120
CE402A	HP CLJ 500 M551	6	1890	2120
CE403A	HP CLJ 500 M551	6	1890	2120
CE250X	HP CLJ CM3530 / CP3525	10,5	1890	2050
CE260X	HP CLJ CP4025/ CP4525	17	2290	2450
CE410X	HP CLJ 300 M351 / 400 M451/ 300 MFP M375/400 MFP M475	4,4	890	1250
CE411A	HP CLJ 300 M351 / 400 M451/ 300 MFP M375/400 MFP M475	2,6	850	1150
CE412A	HP CLJ 300 M351 / 400 M451/ 300 MFP M375/400 MFP M475	2,6	850	1150
CE413A	HP CLJ 300 M351 / 400 M451/ 300 MFP M375/400 MFP M475	2,6	850	1150
CE264X	HP CLJ CM4540 MFP	17	2200	2850
CF031A	HP CLJ CM4540 MFP	12,5	2150	2800
CF032A	HP CLJ CM4540 MFP	12,5	2150	2800
CF033A	HP CLJ CM4540 MFP	12,5	2150	2800
CE270A	HP CLJ CP 5520/ CP5525	13,5	3250	3850
CE271A	HP CLJ CP 5520/ CP5525	15	3250	3850
CE272A	HP CLJ CP 5520/ CP5525	15	3250	3850
CE273A	HP CLJ CP 5520/ CP5525	15	3250	3850
CF210X	HP LaserJet 200 Color M251 / MFP M276	2,4	890	990
CF211A	HP LaserJet 200 Color M251 / MFP M276	1,8	850	950
CF212A	HP LaserJet 200 Color M251 / MFP M276	1,8	850	950
CF213A	HP LaserJet 200 Color M251 / MFP M276	1,8	850	950
CB380A	HP ColorLaserJet CP6015	16,5	1850	2100
CB390A	HP ColorLaserJet CM6030/ CM6040	19,5	1750	2050
CB381A	HP ColorLaserJet CP6015/ CM6030/ CM6040	21	1950	2400
CB382A	HP ColorLaserJet CP6015/ CM6030/ CM6040	21	1950	2400
CB383A	HP ColorLaserJet CP6015/ CM6030/ CM6040	21	1950	2400
C8550A	HP Color LaserJet 9500	25	2650	2950



C8551A	HP Color LaserJet 9500	25	2650	2950
C8552A	HP Color LaserJet 9500	25	2650	2950
C8553A	HP Color LaserJet 9500	25	2650	2950
Q6460A	HP Color LaserJet CM4730	12	1950	2390
Q6461A	HP Color LaserJet CM4730	12	1950	2390
Q6462A	HP Color LaserJet CM4730	12	1950	2390
Q6463A	HP Color LaserJet CM4730	12	1950	2390
CF350A	HP Color LaserJet M153/ M176/ M177	1,3	1250	1450
CF351A	HP Color LaserJet M153/ M176/ M177	1	1150	1450
CF352A	HP Color LaserJet M153/ M176/ M177	1	1150	1450
CF353A	HP Color LaserJet M153/ M176/ M177	1	1150	1450
CE340A	HP LJ LaserJet Enterprise 700 color MFP M775	13,5	5250	6050
CE341A	HP LJ LaserJet Enterprise 700 color MFP M775	16	5250	6050
CE342A	HP LJ LaserJet Enterprise 700 color MFP M775	16	5250	6050
CE343A	HP LJ LaserJet Enterprise 700 color MFP M775	16	5250	6050
<b>Kyocera</b>				
TK-17	Kyocera Mita FS-1000/ 1000+/ 1010/ 1050	6	550	
TK-18	Kyocera FS-1018/1118/1020 7.2K	7,2	490	
TK-60	Kyocera FS-1800/1800+/3800	20	1190	
TK-65	Kyocera FS-3820N/ FS-3830N	20	1190	
TK-100	Kyocera KM-1500/FS1000+/1010 /1050/1020D/1018MFP/1118	6	550	
TK-120	Kyocera FS-1030D	7,2	690	
TK-130	Kyocera FS-1300D/1300DN/FS-1028MFP/1028MFP DP/1128MFP	7,2	690	
TK-140	Kyocera Mita FS-1100/1100N.	4	450	
TK-310	Kyocera FS-2000D, FS-3900DN, FS-4000DN	12	750	
TK-320	Kyocera FS-3900DN, FS-4000DN	15	850	
TK-350	Kyocera FS-3920DN/3040MFP/3140MFP	15	850	
TK-410	Kyocera KM-1620/1635/1650/2020/2050	15	850	
TK-170	Kyocera FS-1320D/ FS-1370DN	7,2	690	
TK-360	Kyocera FS-4020DN	20	1290	
TK-160	Kyocera FS-1120	2,5	390	
TK-340	Kyocera FS-2020	12	750	

TK-435	Kyocera Mita TASKalfa 180/ 181/ 220/ 221	15	850	
TK-715	Kyocera KM-3050/4050/5050	34	2590	
TK-475	Kyocera FS-6025MFP/ 6030/ 6525/ 6530	15	850	
TK-120	Kyocera Mita FS-1030	7,2	690	
TK-330	Kyocera Mita FS-4000	20	1290	
TK-1100	Kyocera FS-1110/1024MFP/1124MFP	2,1	450	
TK-1130	Kyocera FS-1030MFP/ FS-1130MFP	3	490	
TK-1140	Kyocera FS-1035 / FS-1135	7,2	690	
TK-675	Kyocera Mita KM-2540/2560/3040/3060/TASKALFA 300	20	1290	
TK-710	Kyocera FS-9130 / 9530DN.	40	2350	
TK-55	Kyocera Mita FS-1920	15	990	
TK-1120	Kyocera Mita FS-1060DN/1025MFP/1125MFP	3	490	
TK-1110	Kyocera Mita FS-1040/1020MFP/1120MFP	2,5	450	
TK-3100	Kyocera FS-2100D/FS-2100DN	12,5	1150	
TK-3130	Kyocera FS-4200DN/4300DN	25	1390	
KM-1525 / KM-1530 / KM-2030	Kyocera Mita KM-1525/ 1530/ 1570/ 2030/ 2070	11	690	
TK-3110	Kyocera FS-4100DN	15,5	1050	
TK-6305	Kyocera TASKalfa 3500i/4500i/5500i	35	2850	
370AB000	Kyocera Mita KM-2530/3035/3530/4030/4035/5035	34	2870	
TK-450	Kyocera FS-6970DN	15	990	
TK-580K	Kyocera Mita FS-C5150DN	3,5	490	
TK-580C	Kyocera Mita FS-C5150DN	2,8	450	
TK-580Y	Kyocera Mita FS-C5150DN	2,8	450	
TK-580M	Kyocera Mita FS-C5150DN	2,8	450	
TK-590K	Kyocera FS-C2026MFP/ FS-C2126MFP/ FS-C2526MFP/ FS-C2626MFP/ FS-C5250DN	7	1950	
TK-590C	Kyocera FS-C2026MFP/ FS-C2126MFP/ FS-C2526MFP/ FS-C2626MFP/ FS-C5250DN	5	1790	
TK-590Y	Kyocera FS-C2026MFP/ FS-C2126MFP/ FS-C2526MFP/ FS-C2626MFP/ FS-C5250DN	5	1790	
TK-590M	Kyocera FS-C2026MFP/ FS-C2126MFP/ FS-C2526MFP/ FS-C2626MFP/ FS-C5250DN	5	1790	
TK-895K	Kyocera FS-C8020MFP/ FS-C8025MFP/ FS-C8520MFP/ FS-C8525MFP	12	2250	
TK-895C	Kyocera FS-C8020MFP/ FS-C8025MFP/ FS-C8520MFP/ FS-C8525MFP	6	2050	
TK-895Y	Kyocera FS-C8020MFP/ FS-C8025MFP/ FS-C8520MFP/ FS-C8525MFP	6	2050	
TK-895M	Kyocera FS-C8020MFP/ FS-C8025MFP/ FS-C8520MFP/ FS-C8525MFP	6	2050	
TK-8305K	Kyocera TASKalfa 3050ci/3550ci	25	2850	

TK-8305C	Kyocera TASKalfa 3050ci/3550ci	15	2850	
TK-8305Y	Kyocera TASKalfa 3050ci/3550ci	15	2850	
TK-8305M	Kyocera TASKalfa 3050ci/3550ci	15	2850	
<b>Samsung</b>				
ML 1210 / 109R00639	Samsung ML1210/4500/5100 // Xerox Phaser 3110/3210	2,5	650	830
ML 1520D2 / ML 1710	Samsung ML 1520/1710 // Xerox Phaser 3115/3116/3120/ 3121/3130/	2	650	830
ML 1610 / SCX-4521/ 106R01159	Samsung ML1610/ ML2010/ SCX4521 // Xerox Phaser 3117/3122/3124/3125	2	650	830
ML 1710 / 109R00748 / 113R00667	Samsung ML1710 // Xerox Phaser 3115/3116/3120/3121/3130/	2	550	790
ML 2010D3 / ML 1610	Samsung ML 2010/215/1610	2	550	790
ML 2150	Samsung ML 2150/2151/2152	8	850	1150
ML 2250	Samsung ML-2250/2251/2252	5	750	900
ML 2550	Samsung ML 2550/2551N/2552W	8	1250	1500
ML 4500 / ML 1210	Samsung ML-4500/4600/1210	2,5	590	830
ML-D4550A	Samsung ML-4550 / ML-4050 / ML-4551	10	1650	1790
ML D1630A	Samsung ML-1630/SCX-4500	2	750	1030
MLT D108S	Samsung ML-1640/1641, 2240/2241	1,5	650	830
MLT D109S	Samsung SCX-4300	2	590	790
MLT D209L	Samsung SCX-4828/4824/ML-2855	5	790	950
SCX 4100D3 / ML 1710	Samsung SCX-4100/ML 1710	2	590	790
SCX 4521 / ML 1610	Samsung SCX-4521	2	590	790
SCX 4200	Samsung SFX 4200	3	650	800
SCX 4720	Samsung SCX-4720	5	790	950
SF 5100 / ML 1210	Samsung SF-515/530/531/SF-5100/ML 1210	2,5	590	830
MLT-D105L	Samsung ML1910/1915/2525/2580N SCX4600/4623	2,5	690	890
SCX 4725	Samsung SCX-4725	3	550	750
ML-D3050A	Samsung ML-3050 3051N 3051ND	4	690	950
MLT-D104S	Samsung ML-1660/1665/1667// SCX-3200/3205/3207	1,5	650	820
MLT-D208L	Samsung SCX-5635FN/SCX-5835FN	10	890	1150
ML-D2850B	Samsung ML-2850 / 2851	5	790	990
SCX-6320D8	Samsung SCX- 6220 / 6320	8	750	1050
SCX-6320R2 (Drum-unut)	Samsung SCX- 6220 / 6320	20	1590	1750
SCX-D5530B	Samsung SCX-5330N/5530FN	8	790	1050

ML-D3470B	Samsung ML-3470D/3471ND.	10	850	1150
MLT-D205L	Samsung ML-3310/3710/SCX-5637/4833	5	730	930
ML-D3050B	Samsung ML-3050 3051N 3051ND	10	790	1100
ML-3560	Samsung ML3560 /3561	12	1390	1550
MLT-D106S	Samsung ML-2245	2	490	630
MLT-D103S	Samsung ML-2950 / ML-2955 / SCX-4728/ SCX-4729	1,5	690	950
MLT-D307L	Samsung ML-4510ND/ 5010/5015ND	15	1790	1950
MLT-D309L	Samsung ML-5510N/5510ND/6510ND	30	2690	2950
MLT-D101S	Samsung ML-2160/2165/2165W/ 2167/ 2168/SCX-3400/3405/3400F/3405W/3407/ SF-760	1,5	650	850
MLT-D103L	Samsung ML-2950 / ML-2955 / SCX-4728/ SCX-4729	2,5	790	950
MLT-D205E	Samsung ML-3310/3710/SCX-5637/4833	10	950	1300
SCX-D6345A	Samsung SCX 6345	20	2250	2550
SCX-R6345A (Drum-unit)	Samsung SCX 6345	60	3150	3550
SCX-D6555A	Samsung SCX 6545/6555	25	2290	2450
SCX-R6555A (Drum-unit)	Samsung SCX 6545/6555	80	3290	3650
SCX-5312D6	Samsung SCX-5112 / 5115 / 5312 / 5315/ SF-830 / 835P	6	950	1250
SCX-5315R2 (Drum-unit)	Samsung SCX-5112 / 5115 / 5312 / 5315/ SF-830 / 835P	15	1550	1950
MLT-D305L	Samsung ML-3750ND	15	1090	1350
MLT-D117S	Samsung SCX-4650 / SCX-4655	2,5	990	1300
MLT-D307E	Samsung ML-4510ND/ 5010/5015ND	20	2650	3050
MLT-D119S	Samsung ML-1610 / 1615 / 1620 / 1625/ 2010 / 2015 / 2020 / 2510 / 2570 / 2571/ SCX-4321/4521F	2	690	830
ML-D4550B	Samsung ML-4550 / ML-4050 / ML-4551	20	1750	1950
MLT-D115L	Samsung Xpress M2620 /2670 /2820/ 2870	3	1190	1350
MLT-D203L	Samsung M3320/ 3370/ 3820/ 3870/ 4020/ 4070	5	1350	1700
MLT-D203E	Samsung M3320/ 3370/ 3820/ 3870/ 4020/ 4070	10	2150	2400
MLT-D203U	Samsung M3320/ 3370/ 3820/ 3870/ 4020/ 4070	15	2850	3150
<b>Xerox</b>				
006R01278	Xerox WorkCentre 4118	8	950	1290
013R00625	Xerox WorkCentre 3119	3	550	620
106R00586	Xerox WC Pro M15/M15i	6	850	1190
106R00688	Xerox Phaser 3450	5	850	1190

106R01034	Xerox Phaser 3420 / 3425	10	950	1350
106R01048	Xerox WC Pro M20/M20i	8	890	1190
106R01149	Xerox Phaser 3500	12	1050	1450
106R01159 / ML1610	Xerox Phaser 3117/3122/3124/3125 // Samsung ML1610	2	650	890
106R01245	Xerox Phaser 3428	4	650	8550
106R01246	Xerox Phaser 3428	8	890	1190
106R01379	Xerox Phaser 3100 MFP	6	1150	1480
106R01487	Xerox WorkCentre 3210/3220	4,1	790	990
109R00639 / ML 1210	Xerox Phaser 3110/3210 // Samsung ML1210	2,5	650	850
109R00725/ ML 1710	Xerox Phaser 3120/3121/3130 // Samsung ML1710	2	630	850
109R00747	Xerox Phaser 3150	5	750	950
109R00748 / 113R00667/ ML1710	Xerox WorkCentre PE16/PE114e // Samsung ML1710	3	690	890
013R00606	Xerox WorkCentre PE120/PE120i	5	750	950
013R00607 /ML 1710	Xerox WorkCentre PE114e // Samsung ML1710	3	650	890
013R00621	Xerox WorkCentre PE220	3	590	790
113R00735	Xerox Phaser 3200 MFP	2	550	790
108R00909	Xerox Phaser 3140/3155/3160	2,5	790	950
106R01412	Xerox Phaser 3300	8	790	950
106R01374	Xerox Phaser 3250	5	790	950
106R01415	Xerox Phaser 3435	10	850	1190
106R01277 (2 tubes)	Xerox WorkCentre 5016/5020	2x6,3	790	
101R00432 (Drum-unit)	Xerox WorkCentre 5016/5020	22		2590
113R00671 (Drum-unit)	Xerox WorkCentre M20/M20i/4118	20		1550
113R00663 (Drum-unit)	Xerox WorkCentre M15/312	15		1490
113R00712	Xerox Phaser 4510	19	1190	1390
106R01531	Xerox WorkCentre 3550	11	990	1490
113R00668	Xerox Phaser 5500	30	1090	1490
113R00670 (Drum-unit)	Xerox Phaser 5500/5550	60		3350
108R00794	Xerox Phaser 3635	5	890	1350
108R00796	Xerox Phaser 3635	10	990	1490
106R01371	Xerox Phaser 3600	14	1250	1490
006R01182	Xerox CopyCentre C123/128/133, WorkCentre 123/128/133	30	890	1290
006R01044	Xerox WorkCentre 315/320/415/420	2x6,0	750	

013R00577 (Drum-unit)	Xerox WorkCentre Pro 315/320	27		3490
006R01179	Xerox CopyCentre C118 / WorkCentre 118	11	1050	
101R00434 / 101R00435 (Drum-Unit)	Xerox WorkCentre 5222/5225/5230	80		3690
106R01413	Xerox WorkCentre 5222	20	1090	1590
106R01305	Xerox WorkCentre 5225/5230	30	1050	1290
113R00657	Xerox Phaser 4500	18	1690	1950
106R01294	Xerox Phaser 5550	35	1690	1950
006R01020	Xerox 5915/5918/5921	6	690	890
013R00589 (Drum-unit)	Xerox CC C118/ C123/ C128/ C133, WC M118/ M123/ M128/ M133	60		1250
106R02183	Xerox Phaser 3010/3040/ WorkCentreWC3045	2,3	390	490
006R01046-2 tubes	Xerox WC 5632/5638/5645/5655/5735/ 5745/ WC Pro 232/238/235/245/255/DC 535/545/555	2x30	3650	
113R00737	Xerox Phaser 5335	10	1950	2390
113R00619	Xerox WC Pro 423/428, DC 423/428	28,8	2250	3190
113R00730	Xerox Phaser 3200 MFP	3	650	850
106R00646	Xerox Phaser 3310	6	1190	1390
106R01410	Xerox WorkCentre 4250 / 4260	25	1850	2290
113R00755 (Drum -unit)	Xerox WorkCentre 4250 / 4260	80		5450
106R01536	Xerox Phaser 4600/4620	30	3350	
006R01160	Xerox WorkCentre 5325/5330/5335	30	2150	
006R01238	Xerox 6204/6604/6605	2,1		5000
006R01374	Xerox 6279	34,2		5000
113R00495	Xerox Phaser 5400	20	2550	2790
106R02310	Xerox WorkCentre 3315/3325	5	1150	1390
106R02312	Xerox WorkCentre 3325	11	1050	1550
106R01372	Xerox Phaser 3600	20	1950	2390
106R02304	Xerox Phaser 3320	5	1750	
106R02306	Xerox Phaser 3320	11	1850	
006R01276	Xerox WorkCentre 4150	20	2790	
013R00623 (Drum -unit)	Xerox WorkCentre 4150	55		4350
006R01573	Xerox WorkCentre 5019/5021	9	690*	
013R00670 (Drum -unit)	Xerox WorkCentre 5019/5021	80		4490
101R00023 (Drum -unit)	Xerox WorkCentre 415/420	27		3490

013R00591 (Drum -unit)	Xerox WorkCentre 5325/5330/5335	90		4750
006R01046-1tube	Xerox WC 5632/5638/5645/5655/5735/ 5745/ WC Pro 232/238/235/245/255/DC 535/545/555	30	1850	
113R00296	Xerox p8e // Lexmark OPTRA E310/E312	5	1150	1390
106R01203	Xerox Phaser 6110	1,5	330	
106R01204	Xerox Phaser 6110	1	330	
106R01205	Xerox Phaser 6110	1	330	
106R01206	Xerox Phaser 6110	1	330	
106R01476	Xerox Phaser 6121	2,5	1490	
106R01475	Xerox Phaser 6121	2,5	1490	
106R01474	Xerox Phaser 6121	2,5	1490	
106R01473	Xerox Phaser 6121	2,5	1490	
106R01481	Xerox Phaser 6140	2	590	
106R01482	Xerox Phaser 6140	2	590	
106R01483	Xerox Phaser 6140	2	590	
106R01484	Xerox Phaser 6140	2,6	590	
113R00723	Xerox Phaser 6180	6	2390	
113R00724	Xerox Phaser 6180	6	2390	
113R00725	Xerox Phaser 6180	6	2150	2450
113R00726	Xerox Phaser 6180	8	2150	2450
106R01631	Xerox Phaser 6000 / 6010	1	750	
106R01632	Xerox Phaser 6000 / 6010	1	750	
106R01633	Xerox Phaser 6000 / 6010	1	750	
106R01634	Xerox Phaser 6000 / 6010	2	750	
106R01400	Xerox Phaser 6280	5,9	2190	2690
106R01401	Xerox Phaser 6280	5,9	2190	2690
106R01402	Xerox Phaser 6280	5,9	2190	2690
106R01403	Xerox Phaser 6280	7	2190	2690
106R01443	Xerox Phaser 7500	17,8	1950	2390
106R01444	Xerox Phaser 7500	17,8	1950	2390
106R01445	Xerox Phaser 7500	17,8	1950	2390
106R01446	Xerox Phaser 7500	19,8	1950	2390
106R01601	Xerox Phaser 6500/WC 6505	2,5	1050	

106R01602	Xerox Phaser 6500/WC 6505	2,5	1050	
106R01603	Xerox Phaser 6500/WC 6505	2,5	1050	
106R01604	Xerox Phaser 6500/WC 6505	3	1050	
006R01223 / 006R01449	Xerox DC 240/242/250/252/260//WC 7655/7665/7675/7755/ 7765/7775	30	3000	
006R01224 / 006R01450	Xerox DC 240/242/250/252/260//WC 7655/7665/7675/7755/ 7765/7775	34	3900	
006R01225 / 006R01451	Xerox DC 240/242/250/252/260//WC 7655/7665/7675/7755/ 7765/7775	34	3900	
006R01226 / 006R01452	Xerox DC 240/242/250/252/260//WC 7655/7665/7675/7755/ 7765/7775	34	3900	
106R01160	Xerox Phaser 7760	25	3000	
106R01161	Xerox Phaser 7760	25	3000	
106R01162	Xerox Phaser 7760	25	3000	
106R01163	Xerox Phaser 7760	32	2500	
108R00713 (Drum-unit)	Xerox Phaser 7760	35		6250
006R01379	Xerox 700 Digital Color Press	20		1990
006R01380	Xerox 700 Digital Color Press	22		3000
006R01381	Xerox 700 Digital Color Press	22		3000
006R01382	Xerox 700 Digital Color Press	22		3000
106R01335	Xerox Phaser 6125	1	390	
106R01336	Xerox Phaser 6125	1	390	
106R01337	Xerox Phaser 6125	1	390	
106R01338	Xerox Phaser 6125	2	390	
108R00861 (Drum-unit)	Xerox Phaser 7500	80		3050
106R00652	Xerox Phaser 7750	32	1590	1750
106R00653	Xerox Phaser 7750	22	1850	2150
106R00654	Xerox Phaser 7750	22	1850	2150
106R00655	Xerox Phaser 7750	22	1850	2150
108R00581 (Drum-unit)	Xerox Phaser 7750	32		4950
006R01271	Xerox WC 7132/7232/7242	8		2390
006R01272	Xerox WC 7132/7232/7242	8		2390
006R01273	Xerox WC 7132/7232/7242	8		2390
006R01319	Xerox WC 7132/7232/7242	21		2750
013R00636 (Drum-unit)	Xerox WC 7132/7232/7242	80		6050
106R01570	Xerox Phaser 7800	17,2	4500	
106R01571	Xerox Phaser 7800	17,2	4500	



106R01572	Xerox Phaser 7800	17,2	4500	
106R01573	Xerox Phaser 7800	24	4500	
106R01582 (Drum-unit)	Xerox Phaser 7800	145		5250
006R01517	Xerox WorkCentre 7525/7530/7535/7545/7556	26		2590
006R01518	Xerox WorkCentre 7525/7530/7535/7545/7556	15		3190
006R01519	Xerox WorkCentre 7525/7530/7535/7545/7556	15		3190
006R01520	Xerox WorkCentre 7525/7530/7535/7545/7556	15		3190
013R00662 (Drum-unit)	Xerox WorkCentre 7525/7530/7535/7545/7556	125		5250
16197700	Xerox Phaser 7300	15	2850	
16197800	Xerox Phaser 7300	15	2850	
16197900	Xerox Phaser 7300	15	2850	
16198000	Xerox Phaser 7300	15	2850	
16199300 (Drum-unit)	Xerox Phaser 7300	30		4250
16199400 (Drum-unit)	Xerox Phaser 7300	30		4250
16199500 (Drum-unit)	Xerox Phaser 7300	30		4250
16199600 (Drum-unit)	Xerox Phaser 7300	30		4250
106R01077	Xerox Phaser 7400	18	1900	
106R01078	Xerox Phaser 7400	18	1900	
106R01079	Xerox Phaser 7400	18	1900	
106R01080	Xerox Phaser 7400	15	1900	
108R00647 (Drum-unit)	Xerox Phaser 7400	30		4250
108R00648 (Drum-unit)	Xerox Phaser 7400	30		4250
108R00649 (Drum-unit)	Xerox Phaser 7400	30		4250
108R00650 (Drum-unit)	Xerox Phaser 7400	30		3800
006R01461	Xerox WorkCentre 7120/7125/7220/7225	22	2750	
006R01462	Xerox WorkCentre 7120/7125/7220/7225	15	3750	
006R01463	Xerox WorkCentre 7120/7125/7220/7225	15	3750	
006R01464	Xerox WorkCentre 7120/7125/7220/7225	15	3750	
006R01529	Xerox Color 550/560	30	2100	
006R01530	Xerox Color 550/560	34	3250	
006R01531	Xerox Color 550/560	32	3250	
006R01532	Xerox Color 550/560	34	3250	
006R90280	Xerox DC 12	7,4	1220	

006R90281	Xerox DC 12	9,4	1220	
006R90282	Xerox DC 12	9,4	1220	
006R90283	Xerox DC 12	9,4	1220	
006R01175	Xerox WC 7228/7235/7245/7328/7335/7345 WCPPro C2128/C2636/C3545	26		2400
006R01176	Xerox WC 7228/7235/7245/7328/7335/7345 WCPPro C2128/C2636/C3545	16		2400
006R01177	Xerox WC 7228/7235/7245/7328/7335/7345 WCPPro C2128/C2636/C3545	16		2400
006R01178	Xerox WC 7228/7235/7245/7328/7335/7345 WCPPro C2128/C2636/C3545	16		2400
106R01282	Xerox Phaser 6130	1,9	530	
106R01283	Xerox Phaser 6130	1,9	530	
106R01284	Xerox Phaser 6130	1,9	530	
106R01285	Xerox Phaser 6130	2,5	530	
106R01523	Xerox Phaser 6700	12		3200
106R01524	Xerox Phaser 6700	12		3200
106R01525	Xerox Phaser 6700	12		3200
106R01526	Xerox Phaser 6700	18		3200
006R01399	Xerox WorkCentre 7425/7428/7435	26		2550
006R01400	Xerox WorkCentre 7425/7428/7435	15		3150
006R01401	Xerox WorkCentre 7425/7428/7435	15		3150
006R01402	Xerox WorkCentre 7425/7428/7435	15		3150
013R00647 (Drum-unit)	Xerox WorkCentre 7425/7428/7435	75		4050
106R00680	Xerox Phaser 6100	5		1700
106R00681	Xerox Phaser 6100	5		1700
106R00682	Xerox Phaser 6100	5		1700
106R00684	Xerox Phaser 6100	7		1700
106R02609	Xerox Phaser 7100	9		4950
106R02610	Xerox Phaser 7100	9		4950
106R02611	Xerox Phaser 7100	9		4950
106R02612	Xerox Phaser 7100	10		2650
013R00624 (Drum-unit)	Xerox WC 7228/7235/7245/7328/7335/7345 WCPPro C2128/C2636/C3545	50		3550
013R00657 (Drum-unit)	Xerox WorkCentre 7120/7125/7220/7225	67		5550
013R00658 (Drum-unit)	Xerox WorkCentre 7120/7125/7220/7225	51		5550
013R00659 (Drum-unit)	Xerox WorkCentre 7120/7125/7220/7225	51		5500
013R00660 (Drum-unit)	Xerox WorkCentre 7120/7125/7220/7225	51		5500

106R00672	Xerox Phaser 6250	8	1200	
106R00673	Xerox Phaser 6250	8	1200	
106R00674	Xerox Phaser 6250	8	1200	
106R00675	Xerox Phaser 6250	8	1200	
106R02249	Xerox Phaser 6600N/ WorkCentre (WC) 6605DN	2	1500	
106R02250	Xerox Phaser 6600N/ WorkCentre (WC) 6605DN	2	1500	
106R02251	Xerox Phaser 6600N/ WorkCentre (WC) 6605DN	2	1500	
106R02252	Xerox Phaser 6600N/ WorkCentre (WC) 6605DN	3	1500	
013R00602 (Drum-unit)	Xerox DC 240/242/250/252/260//WC 7655/7665/7675/7755/ 7765/7775	215		5550
013R00603 (Drum-unit)	Xerox DC 240/242/250/252/260//WC 7655/7665/7675/7755/ 7765/7775	70		6550